



## **Executive Summary**

This technical paper provides information for recovering the Windows 7 OS on the obsolete C-Series Rev. B AIO units.

## **Procedure**

These products came equipped with recovery .iso images already built into them. They were located on the desktop in a folder named “***Recovery DVD ISO Files.***”

Instructions for how to use these is found on page 27 of the User’s Guide:

[https://docs.elotouch.com/touchscreen-computers/c-series-touchscreen-computers/SW602048\\_EN.pdf](https://docs.elotouch.com/touchscreen-computers/c-series-touchscreen-computers/SW602048_EN.pdf)

If for some reason you have wiped these files from the system, the below recovery .iso images are being provided as a courtesy. You will need to burn each image on separate DVDs and connect an external USB DVD drive to the Elo AIO and boot from it. Start with Image #1 and then use Image #2.

Image Disk

1: <https://elotouch.sharepoint.com/:u:/s/KnoxvilleTechnicalServices/ET8oFvgxSFBLiR0rdnz6UclBoJibrsCYnjt8LI5JFWKqeA?e=UPQh4c>

Image Disk

2: <https://elotouch.sharepoint.com/:u:/s/KnoxvilleTechnicalServices/EdMHUUeukQIEqAu1U6Pg02gBTBVGkmc6qGwTQtqUUwYPuw?e=bJZQaO>

## **Troubleshooting**

- If a **C:\Windows\System32\** prompt screen comes up when installing, you will need to type in **Win7** and hit enter to install.
- If having problems booting from the DVD drive, go into the system BIOS by tapping the DEL key on the keyboard during startup.
  - Make sure “fast boot” or “quick boot” is not enabled in the BOOT section.
  - Make sure to make your DVD drive the #1 BOOT Device.
  - You might also have to scroll to the bottom of the BOOT section and see if “BBS BOOT Priorities” is listed – if so, you might need to make the DVD drive the #1 BOOT device in that section as well.