

Elo Touch Solutions

Tablet Image Recovery Guide

TS08212013 Rev. C

Elo Technical Solutions Support Services



Copyright © 2013 Elo Touch Solutions, Inc. All Rights Reserved.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Disclaimer

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

Trademark Acknowledgments

AccuTouch, CarrollTouch, Elo, Elo (logo), Elo Touch, Elo Touch Solutions, Elo TouchSystems, IntelliTouch, iTouch, SecureTouch, TouchTools and VuPoint are trademarks of Elo and its affiliates. Windows is a trademark of Microsoft Corporation.

Table of Contents

Introduction	4
Tools Needed	5
Procedure	6
Figures and Files	7

About This Manual

This document guides the user through the successful implementation of recovering the operating system on an Elo Tablet. This process will completely erase all contents of the harddrive and recover the image as it was when first purchased. You are responsible for making backups of personal data/files stored on the system.

The intended audience of this document includes: IT engineers, system engineers, electrical engineers, and end-users.

If after reading through this guide, you still have questions or need help getting your system up and running, please contact an Elo Touch Solutions Technical Representative. <u>www.elotouch.com</u>

Tools Needed

The following hardware and software is needed to recover the operating system on the Elo Tablet.

Hardware:

- Target system = Elo Tablet with docking station
- 8GB (or larger) USB flash drive
- Development system (needed to create the bootable USB recovery drive) = PC with Operating System: XP, Vista, Windows 7

-RAM: 256 Meg

-Disk space: 2MB free hard disk space, plus any additional space required to store image file.

- USB Keyboard for Tablet
- USB Mouse for Tablet

Software:

- Elo Recovery Image.bin: <u>https://elotouch.sharepoint.com/:u:/s/KnoxvilleTechnicalServices/ERBZbHO_bY5KIs7U2sf6K0</u> <u>oBIUQId27hAZGMXE-phsJYDQ?e=szKDqZ</u> (url valid at the time of this writing)
- USB Cloning Utility, ImageUSB by Passmark: https://elotouch.sharepoint.com/:u:/s/KnoxvilleTechnicalServices/EaEREDKyJoRNnUdcAt2ydlg <u>Bb26xOWdNpDc1_CliZquoMg?e=4oraQM</u> (url valid at the time of this writing)

Development System (This process will create a bootable USB flash drive which contains the Elo tablet recovery image):

- 1. Download the Elo Recovery Image Software from Elo
- 2. Download the USB Cloning Utility from Elo
- 3. Insert an 8GB or larger USB flash drive
- 4. Run the USB Cloning Utility. See Fig 1
- 5. Choose the USB flash drive as the USB drive to be processed
- 6. Make certain "Write to UFD" and "Post Image Verification" are selected
- 7. Browse to the location where the Elo Recovery Image has been stored
- 8. Choose "Write to UFD" this process can take several minutes
- 9. After image is written to the USB flash drive, remove from the development system

Target System (This process will restore the tablet to as shipped condition):

- 1. With the Tablet turned off, insert USB flash drive into a USB port on the Elo Tablet
- 2. Connect a USB keyboard and mouse to the tablet at this time
- 3. Press the power button and immediately begin pressing the *F2 key* on the keyboard
- 4. Once inside the BIOS, navigate to the **BOOT** section. <u>See Fig 2</u>
- 5. Make the USB flash drive number one (1.) in the Boot Priority Order. See Fig 2
- 6. Press F10 on the keyboard to save changes
- 7. The Tablet will then restart and will automatically begin the reimaging process. <u>See Fig 3</u> **NOTE:** The reimaging process typically takes 45-60 minutes to complete
- 8. When the imaging process is complete, a command window with a *C*: /prompt will show on the screen. <u>See Fig 4</u>
- 9. Remove the USB flash drive and restart the Elo Tablet

The tablet has now been restored to an as shipped condition. Additional software and or applications loaded post first time boot will now need to be reloaded. Please consult your software or application documentation.

ep 1: Selec	t the USB drive(s) to	be processed.	Others in fe	Chabur		
Drive E:∖ ✓ F:\	Size 2861578 MB 7629 MB	Expansion Dr	USB, NTFS USB, FAT32	Status		
Select All	Unselect All					Refresh Drives
ep 2: Selec Write to I	ct either "Write" to oi UFD () Create from	r "Create" from the n UFD	USB Flash Drive	e (UFD).	P	ost Image Verificatio
ep 2: Selec Write to ep 3: Selec	ct either "Write" to o UFD Create from t the image (.bin or	r "Create" from the n UFD .iso) file to write to	USB Flash Drive	e (UFD). Drive.	Pi	ost Image Verificatio
write to Write to ep 3: Select :\Tablet\Re	ct either "Write" to or UFD Create from t the image (.bin or :covery Image\Table	r "Create" from the n UFD .iso) file to write to tRestoreUnreleased	USB Flash Drive the USB Flash	a (UFD). Drive.	P	ost Image Verificatio
ep 2: Selec Write to ep 3: Selec :\Tablet\Re	tt either "Write" to or UFD Create from t the image (.bin or covery Image\Table the 'Write to UFD' bu	r "Create" from the n UFD .iso) file to write to tRestoreUnreleased utton to begin	USB Flash Drive	a (UFD). Drive.	P P	ost Image Verificatio
Write to Write to Ep 3: Select Tablet\Re Ep 4: Click Write to U	tt either "Write" to or UFD Create from t the image (.bin or covery Image\Table the 'Write to UFD' bu	r "Create" from the n UFD .iso) file to write to tRestoreUnreleased utton to begin	USB Flash Drive	a (UFD). Drive.	P P	ost Image Verificatio
Write to Write to P 3: Select Cablet\Re P 4: Click Write to U Sg output:	tt either "Write" to or UFD Create from t the image (.bin or covery Image\Table the 'Write to UFD' bu FD Overall progr	r "Create" from the n UFD .iso) file to write to tRestoreUnreleased utton to begin ress	USB Flash Drive	a (UFD). Drive.	P	ost Image Verificatio

Fig 2

7			Phoen	ix Secu	reCore Tia	ano Setuj	p	None of the second s
	Main	Advance	ed Sec	urity	Boot	Exit		
	Main Boot P 1. 2. 3. 4. 5. 6. 7. 8.	Advance rioritu Ord USB HDD: S ATA HDDO: USB CD: USB FDD: ATAPI CD: ATA HDD1: Other HDD Internal S	ed Sec ler SanDisk Cr SanDisk S : Shell	uzer SD U100	Boot 32GB	Exit	It Keys conf and devic move down enab	em Specific Help used to view or igure devices: 1 4 arrows Select a ce. '+' and '-' the device up or . 'Shift + 1' les or disables a
	9. F1 He Esc Ex	PCI LAN: I	EFI Networ Lect Item Lect Menu	*/- Enter	Change Va Select ►	lues Sub-Menu	devic an ur F9 F10	Setup Defaults Save and Exit

Fig 3

Progress Indicator				
	25%	50%	75%	100%
0%	23%	50%		
CL III III				
Statistics Percent complete	2		- 1.1	
Speed (MB/min)	446			
MB copied	171		1	7
MB remaining	7778			1
Time elapsed	0:23			/
Time remaining	17:25		1/	
		A DESCRIPTION OF THE OWNER OF THE	and the second second second	
Details	and the second second second	and the second s		
Connection type	Local Local file INT9983	GH0. 30533 MB		
Source	Local drive [2]. 3	1533 MB		
Destination	1/1 Tupe? [NTFS], S	ize: 30531 MB, Windows		
Current parimon	574 (e35be42d-f742	-4d96-a50a-1775fb1a7a42)	
Current ine				
		(S) sym	antec.	
		INCOMPANY INTERNAL SEA	INTERES OF CLASSES IN	WILLIAM ANALONS

Fig 4

Command Prompt		
C:∖>_		^
		*

Check out our website

www.elotouch.com

Get the latest...

- Product Information
- Specifications
- Upcoming events
- Press releases
- Software drivers

Getting in Touch with Us

To find out more about the extensive range of Elo touch solutions, visit our website at www.elotouch.com, or simply call the office nearest you:

North America Elo Touch Solutions 1033 McCarthy Blvd

Milpitas, CA 95035

Tel 800-ELO-TOUCH Tel + 1 408 597 8000 Fax +1 408 597 8050 customerservice @elotouch.com Europe Tel +32 (0) 16 70 45 00 Fax +32 (0)16 70 45 49 elosales@elotouch.com Asia-Pacific Tel +86 (21) 6106 7162 Fax +86 (21) 6485 3981 www.elotouch.com.cn Latin America Tel 786-923-0251 Fax 305-931-0124 www.elotouch.com