ēlo

Elo Touch Solutions
RAM (Memory Module) Replacement ECMG2B/C

TS01122017 Rev A

Elo Touch Solutions Technical Services

Disclaimer

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

Trademark Acknowledgments

AccuTouch, CarrollTouch, Elo, Elo (logo), Elo Touch, Elo Touch Solutions, Elo TouchSystems, IntelliTouch, iTouch, SecureTouch, TouchTools and VuPoint are trademarks of Elo and its affiliates. Windows is a trademark of Microsoft Corporation.

Table of Contents

About This Manual

This procedure details replacing or adding RAM (Memory Module) in the Elo ECMG2B/C computer module.

The intended audience of this document includes: IT engineers, system engineers, electrical engineers, and end-users.

If after reading through this guide, you still have questions or need help getting your system up and running, please contact an Elo Touch Solutions Technical Representative. www.elotouch.com

Tools Needed

The following hardware that is needed:

Hardware:
- Elo ECMG2B/C Computer Module
- #2 Philipps Screwdriver
- Flat blade Screwdriver
- Replacement RAM - DDR3L SO-DIMM 1.35V Low Voltage (laptop memory) 1600MHz
  RAM can be purchased from 3rd party vendors. An example can be found at the following url:
  http://www.memory4less.com/adata-8gb-sodimm-pc12800-adds1600w8g11-bmie (valid at the
 time of this writing).

The following software is needed:

Software:
- N/A

Procedure

1. Using the Philipps screwdriver, remove 7 screws from the top of the module.

2. Using the flat blade screwdriver, remove the slotted silver slide screw from the side of the module.

3. Lift the top cover off of the computer module to gain access to the RAM slots.

4. Disconnect the SATA connector to allow easy access to RAM module.

5. Push the two retaining spring tabs outward to allow RAM module to be removed.

6. Replace or add extra RAM and reassemble ECM computer module by following this procedure in reverse.

Check out our website

www.elotouch.com

Get the latest...

- Product Information

- Specifications

- Upcoming events

- Press releases

- Software drivers

Getting in Touch with Us

To find out more about the extensive range of Elo touch solutions, visit our website at www.elotouch.com, or simply call the office nearest you:

North America		**Europe**	**Asia-Pacific**	**Latin America**
Elo Touch Solutions	Tel 800-ELO-TOUCH	Tel +32 (0) 16 70 45 00	Tel +86 (21) 6106 7162	Tel 786-923-0251
1033 McCarthy Blvd	Tel + 1 408 597 8000	Fax +32 (0)16 70 45 49	Fax +86 (21) 6485 3981	Fax 305-931-0124
Milpitas, CA 95035	Fax +1 408 597 8050	elosales@elotouch.com	www.elotouch.com.cn	www.elotouch.com
	customerservice@elotouch.com			