Settings	Description	Account	Group	Filter	Device
Brightness	Edit brightness on device.	Х	Χ	Х	Х
Volume	Edit volume on device.	Х	Χ	Х	Х
Touch Sound	Enables sound when tapping/typing on thve device	Х	Χ	Х	Χ
Software Update	Update the device software.	Х	Χ	Х	Χ
Control Panel	Use this password to gain full (admin) access to EloView Control Panel	Х	Χ	Х	Х
Password	on the Elo device.				
Access Restriction	Use this password to gain restricted access to EloView Control Panel	Х	Χ	Х	Х
Password	on the Elo device. User cannot update the device (OS), access advanced				
	Android Settings.				
Language	Set Language of device. Languages available: English, Italian, Japanese,	Х	Χ	Х	Х
	Chinese, German, French, Spanish.				
Orientation	Device orientation – Landscape or Portrait	X	X	X	X
Interactive	Adds a navigation bar with a home and back button.	Х	Χ	Х	Х
Overlay	All life in the second	.,,		.,	
Android	Allows access to the app drawer so merchant can navigate to different	Х	Χ	Х	Х
Navigation Bar	apps deployed on device.	V	V		V
Show Stock Apps	Displays all default Elo Apps and Android apps in the EloView Control Panel.	Х	Х		X
NTP URL	Overrides the default Network Time Protocol (NTP) server used by	Х	Χ	Х	Χ
	Android devices for official time-keeping				
	services – android.pool.ntp.org. For example, you may prefer to use a				
	regional server like "asia.pool.ntp.org" or "pool.ntp.org" to access a cluser				
	of public NTP time servers across the internet.				
Device Screenshot	View current screenshot of device.	Х	Χ	Х	Χ
Navigation Bar	Customize the color of the navigation bar.	Х	Χ		Х
Color					
Account Default	Default app deployed to newly-registered devices during the auto-	Х	Χ		Х
	provisioning process.	.,		.,	
Display Timer	Sets timer on display to turn on and off each day. The "on" time will	Х	Χ	Х	Х
(On/Off) Android Home	turn on the device display. The "off" time will turn off the device display.	V	Х	V	
Physical Analytics	Displays the standard Android UI.	X	X	X	X
	Allows device to collect analytics data to determine application effectiveness as measured by impressions vs. touches. This information is		Χ	^	Λ
	displayed in the EloView Dashboard.				
Network	Customize Network configuration	Х	Х	Х	Х
Configuration	Castoffize Network configuration	_ ^	^		^
Auto Play	Allows the device to side-load applications from USB.	Х	Х	Х	Х
Home Button	Allows the physical Home button on the Elo device to behave as intended	X	X	X	X
	in Android i.e. display the app drawer.				
Power Button	Allows the physical Power button on the Elo device to behave as intended	Х	Χ	Х	Х
	in Android i.e. shut down the device.				
Delayed Content	When enabled, new content deployed on EloVlew Portal will be	Х	Χ	Х	Х
Deployment	downloaded to device on specific time as set here.				
Wi-Fi	Enable/Disable Wi-Fi	Х	Χ	Х	Х
Virtual Keyboard	Enables the virtual keyboard for use on the device	Х	Χ	Х	Х
Reboot	Reboots the device.	Х	Χ	Х	Х
Enterprise Reset	Resets data on device	Х	Χ	Х	Χ
Remote Control	Allows remote access to device using TeamViewer		Χ	Х	Χ
(TeamViewer)					
Time Zone	Need to establish, especially for logging purposes.	Х	Х	Х	Χ
GPS Co-ordinate	Establish GPS Coordinates for a device.				Χ
Add Custom	Create custom data fields to store additional information about a	Х	Χ	Х	Χ
Value(s)	device e.g. location (kitchen vs. floor)				