


**Executive Summary**

This Technical Bulletin describes how to manually clear the CMOS / BIOS password on the Elo I-Series units.




**Steps**

1. Turn off unit, remove power supply
2. Using a #1 Philipps screwdriver, remove the 3- screws that hold down the small metal plate on the back of the unit



3. Move jumper to the top 2 pins, wait for two minutes



4. Move jumer back to the original position, the password should now be cleared