

Executive Summary

This procedure explains how to turn off the Elo Logo on current Elo Desktop Monitors. This procedure requires using the Onscreen Display Menu (OSD) buttons on the backside of the monitor as shown in **Figure 1** below:



Figure 1

Steps:

1. Turn the monitor off by pressing the **power** button.
2. Hold the **select** button in and press the **power** button in and allow monitor to turn back on.
3. When video appears on the screen, stop pressing the **select** button.
4. Press the **Menu** button and you will see the OSD menu with a small letter “**F**” in the upper left corner. See **Figure 2** below.
5. Using the **left/right arrow buttons**, scroll to the “**F**” and then press the **select** button to enter the Factory OSD Menu.



Figure 2

- Using the **left/right arrow buttons**, scroll to the **ELO LOGO** section and press the **select** button which will highlight the word **ON**



Figure 3

- Using the **left/right buttons** on the OSD menu, change it to **OFF**, then press the **select** button to save the change.
 - Press the **Menu** button to exit the OSD menu.



Figure 4