

Overview

This technical article describes how to access the WiFi/BT (BlueTooth) Module on the EloPOS AIO unit.


WiFi/BT Specifications

- Elo P/N: E576849 – Module, Intel AC-9260, 802.11ac, BT5.0

Steps

To access the WiFi/BT Module on the EloPOS unit follow the below steps:

1. Disconnect power from the EloPOS unit.
2. Using small, thin prying tool or screwdriver, carefully remove the upper access door.



3. Remove tape, disconnect WiFi antennas, remove Phillips screw from WiFi/BT Module

