

Overview

This technical article describes how to access the WiFi/BT (BlueTooth) Module on the EloPOS AIO unit.

WiFi/BT Specifications

- Elo P/N: E576849 – Module, Intel AC-9260, 802.11ac, BT5.0

Steps

To access the WiFi/BT Module on the EloPOS unit follow the below steps:

1. Disconnect power from the EloPOS unit.
2. Place unit face down on a protective surface and remove the Philipps screw from the lower access panel.



3. Remove lower and upper access panels to gain access to internal components.



4. Remove tape, disconnect WiFi antennas, remove Phillips screw from WiFi/BT Module.
 - a. Replace with compatible WiFi Module.

