Feature/Option	5.8.x Single Touch	6.9.x Multi-Touch
Beep on touch adjustments & controls	Sound tab	Touch Screen Properties
Calibrate	"Align" button on General tab	Button in main dialog
Enhanced (29 point)?	YES	No
Click on touch/release/mouse emulation	Mode tab	Touch Screen Properties
Controller and connection info/status	Properties tab	Touch Screen Properties
Cursor Edge Acceleration	Properties tab, Advaced *	Touch Screen Properties
Define Touch/Exclusion zones	N/A	Button in main dialog
Disable touch	Properties tab, Advaced *	Touch Screen Properties
Double-Click settings	Mode tab	Common Settings
Drag Delay adjustment	Mode tab	N/A
Edge acceleration tool	Properties tab, Advaced *	Touch Screen Properties
Hide mouse pointer	Mode tab	Common Settings
Identify monitor	Properties tab	Touch Screen Properties & About
Left-handed mouse	Mode tab	N/A
Re-Align	N/A	Touch Screen Properties
Restore default calibration	N/A	Touch Screen Properties
Right-click area adjustment	Properties tab, Advaced *	N/A
Right click on hold	Properties tab, Advaced *	N/A
Show right mouse button tool	Properties tab, Advaced *	N/A
Show tool tray utility	Mode tab	N/A
Single Touch/Double Touch selection	N/A (single touch only)	Touch Screen Properties
Spanned Display mode	N/A	Common Settings
Untouch timeout adjustment	Mode tab (defaults to 10 seconds)	N/A (deafaults to controller max)
Information in "About"	Driver version number	EloConfig version, time built
	Readme	Online Support (link to web site)
	User Manual	User Manual
	Link to Elo web site Home page	Component versions
		Identify Monitors button

 $^{^{}st}$ Advanced button will not show until monitor has been calibrated/aligned