

Technical Bulletin: TB000149 – EC update for EloPOS / WLIDS

Overview

This technical bulletin describes how to update the EC firmware in Elo EloPOS and I-Series 2.0 for Windows (WLIDS) devices.

Applicable Elo Devices

EloPOS: E3/E5/S3/S5/H3/H5

WLIDS: i3/i5

Tools & Hardware Needed


- EloPOS E3/E5/S3/S5/H3/H5 and WLIDS i3/i5
- USB cable Depending on unit model number:
 - o **WLIDS:** USB power supply E903506 Power Brick, type C 100W, FSP.
 - o **EloPOS:** Power supply E511572 AIO POWER BRICK, 24V 180W, DELTA.
- Keyboard (optional)
- USB Thumb Drive 2MB or greater

Software Needed

 E3E5_EC_E205.20A_0.27 (EC files) Download .zip package here: https://elotouch.sharepoint.com/:u:/s/KnoxvilleTechnicalServices/Eb-V2IG6CMJAhgtHLDIi pUBL-kzmBcAptNegiDFrGQy2A?e=bd7ovp

Steps for Preparing USB Flash Drive

- 1. Prepare a USB flash drive (Formatted to FAT32). The minimum required size of the flash drive is 2MB.
 - a. To Format USB Flash drive to FAT 32:
 - i. Connect **USB drive** to the device and *click on* **Open folder to view files** option.
 - ii. Right-click on your **USB drive** and click-on **Format** option.
 - iii. From the window, select FAT32 from the drop-down bar under File system.
 - iv. Click-on Start and OK to begin the formatting process.
 - v. Once the formatting is completed *click-on* **OK**.
- 2. Copy the files and folder from "E3E5_EC_E205.20A_0.27" folder onto root of USB drive, as follows.





Steps for Updating WLIDS Units

1. Remove Cable cover to access the USB power



- 2. Plug in USB C power adapter and USB thumb drive as shown.
 - a. Do not rest the unit onto the USB drive, support device with foam or cardboard.




- 3. Power on unit.
- 4. During boot up *press* **Del key** on keyboard *or press* **SETUP icon** to enter **BIOS**.








5. Under the **Main tab**, check current **EC Version**. In example below EC Version is: **v0.21** (your device's EC version may be different). If your device's EC Version is already **v0.27**, there is no need to do this update. Otherwise, proceed to **step 6**.



6. Under Save and Exit tab, scroll down to the Boot Override section, and double-click UEFI.



7. The unit will automatically launch into the update screen. You will see a series of messages. Do not interrupt or remove power during update.



- 8. When completed, the system will reboot to Elo splash screen.
 - At this point, remove the USB drive and enter Setup, (if the USB drive is not removed, the unit will launch into the update continuously and continue to reboot).
 - If the operator misses the BIOS boot, restart without the USB drive connected and press Del on the keyboard or press Setup icon to enter Setup.
 - o Under Main tab verify EC version is 2020.05.20 v0.27 If not, repeat steps 4-6.





Steps for Updating EloPOS Units

1. Install USB Flash Drive as shown



2. Plug in DC Power Adapter as shown




- 3. Power on unit.
- 4. During boot up *press* **Del key** on keyboard *or press* **SETUP icon** to enter **BIOS**.








5. Under the **Main tab**, check current **EC Version**. In example below EC Version is: **v0.21** (your device's EC version may be different). If your device's EC Version is already **v0.27**, there is no need to do this update. Otherwise, proceed to **step 6**.



6. Under Save and Exit tab, scroll down to the Boot Override section, and double-click UEFI.



7. The unit will automatically launch into the update screen. You will see a series of messages. Do not interrupt or remove power during update.



- 8. When completed, the system will reboot to Elo splash screen.
 - At this point, remove the **USB drive** and enter **Setup**, (if the USB drive is not removed, the unit will launch into the update continuously and continue to reboot).
 - If the operator misses the BIOS boot, restart without the USB drive connected and press Del on the keyboard or press Setup icon to enter Setup.
 - o Under Main tab *verify* EC version is 2020.05.20 v0.27 If not, repeat steps 4-6.

