


Executive Summary

This Tech Bulletin describes how to use the built in Windows 10 Task Scheduler on an Elo AIO Touchcomputer to perform an automatic restart on a daily schedule.


Procedure

1. How to schedule an automatic restart in Windows 10 using Task Scheduler.


Press **Win** + **R** keys together on the keyboard and type **taskschd.msc** in the Run box. Press Enter or click on the OK button.




2. When the Task Scheduler appears, click on **Create Basic Task**




3. Give the task a **Name** and **Description**, then click **Next**




4. Select when you want the task to be ran, then click **Next**.




5. Set the **Start** date, enter the time you want task to begin, and how often the task will occur. If doing this on multiple machines in different time zones you may want to select the Synchronize across time zones option. Then click **Next**.



6. Choose the action you want to take place, then click on **Next**.



7. Type in **shutdown** in the Program/script field, type **/r** in the Add arguments field, then click **Next**.



8. Check over the task and verify everything is correct. If something needs to be changed choose the **Back** option and go back and edit. If all is good, click **Finish**.

