

Introduction

A command line utility is available to write the existing Elo driver settings to a file. The file may then be copied to a new system and the utility run to copy the settings from the file to the registry on the new system. A system reboot then makes the new system's touch settings the same as the parent system's touch settings. This document refers to the Elo Single-Touch driver version 5.8.2

- **elodriverdefaults.exe** is the utility
- **elooptions.ini** is the Elo options file


Overview

The utility is executed with the following three options:

- c** **copies** the existing driver **settings to the registry**
 - r** **reads** the registry settings and writes them **to the elooptions.ini file**
*(both **-c** and **-r** must be done to update the options file)*
 - w** **writes** the file settings **to the registry** on the target system
(a reboot is required to make the settings take effect)
- *Note: "Apply" or "OK" does not copy the Elo Control Panel changes to the registry – you must execute the utility with the **-c** flag to update the registry*
 - *The Elo touch version 5.8.2 driver must be installed on the original and target systems.*
 - *The utility must be run from an Admin command line; it will not execute properly in the Windows environment. This procedure assume you know how to use a Windows Command Prompt.*
 - *The utility must be run from the directory where the driver files reside.*

Procedure

1. **Install the Elo Single-Touch 5.8.2 driver** onto the original and target systems
2. Use the **Elo Control Panel** to **calibrate and configure** the driver settings/options as desired. Be sure to *apply* the settings with the **Apply** or **OK** buttons.
 - a) Open an Admin command prompt: Press **Windows+R** on the keyboard to open the **Run** box
 - b) Type **cmd** in the text box and press **Ctrl+Shift+Enter** on the keyboard to run it with admin privileges.
 - c) A Windows Command line window should open:



- 
- A screenshot of a Windows Command Prompt window. The title bar at the top reads "C:\ Command Prompt". The main area of the window is black with white text. The current directory is displayed as "C:\Program Files\Elo Touch Solutions>" on a single line.



- 
- The screenshot shows a Windows Command Prompt window with the title bar 'C:\ Command Prompt'. The command prompt displays the directory path 'C:\Program Files\Elo Touch Solutions' followed by the command 'elodriverdefaults =c'.

- 
- The screenshot shows a Windows Command Prompt window. The title bar reads "C:\ Command Prompt". The command prompt shows the current directory as "C:\Program Files\Elo Touch Solutions" and the command "elodriverdefaults -r" has been entered and executed.

-

To import the copied settings to target computers:

Make sure the Elo 5.8.2 driver is installed on the target system (when installing **on the target systems**, *uncheck* “**Calibrate Elo Monitors**” when prompted.)

1. Navigate to the location of the drivers: C:\Program Files\Elo Touch Solutions**2. Replace the default eloptions.ini file with the one you saved.****3. Open an Admin cmd prompt and execute the command to write the settings to the registry: Elodriverdefaults -w****4. Restart the computer.****5. Connect any identical Elo Touch Solutions monitor to the system and it will automatically be aligned without any user interaction.**